

Installing the Aux-2 Harness



See the website at <http://www.kawal.net/auxinput.htm> for more photos and details.

1. Find your XM receiver per the instructions and unplug the 16 pin connector. Plug that connector on the body harness into the Aux-2 harness. Push the connector STRAIGHT into the female mating connector. It should feel right—don't force it—you can bend a pin if you don't push it straight in.
2. Plug the other 16 pin connector into the XM receiver. Again, do not force the connector.
3. Ideally, you should mount the 3.5mm (1/8") jack to a panel. The right side center console panel is suggested, but you'll need a 1/4" hole drilled somewhere to mount the jack.
4. Use the stereo patch cord to connect your music device.
5. Press the XM1/2 button on your radio. You should now hear your audio from your music device instead of XM. When you unplug your patch cord, XM audio will again be heard.

If you have any problems or questions, please email Ray Kawal at ray@kawal.net. My phone number is 360-683-3027 if you would rather discuss the issue by phone.